


Picnic table white 150 cm










3



E 2x

## Care instructions

- Tighten the screws at the end of the construction and check them regularly afterwards
- Do not use power screw drivers as they might cause splitting
- Only use special cleanser or impregnate oil to clean wooden products and water and soap for aluminium and steel products
- Use soft brushes when cleaning to avoid scretching the surface
- Protect your furniture/products with a cover when you are not using it

maximavida.com Den Sliem 42 7141 JH Groenlo +31 544-375445 info@maximavida.com